

**NAME**

dvbnet – a DVB Network Interface Manager.

**SYNOPSIS**

**dvbnet** [*options*]

**DESCRIPTION**

This manual page documents briefly the **dvbnet** commands.

**dvbnet** is a DVB Network Interface Manager.

**OPTIONS**

- a AD** Adapter card (default 0)
- n DD** Demux (default 0)
- p PID** Add interface listening on PID
- d NUM**  
Remove interface NUM
- l** List currently available interfaces
- U** use ULE framing (default: MPE)
- v** Print current version

This manual page was written by Uwe Bugla <uwe.bugla@gmx.de>.